

# Hybrid Racing Performance Shifter Cables TSX Shifter -> K20Z3 Trans

Use these steps as a guide to install your HR shifter cables using a TSX shifter and a K20Z3 transmission.

Written By: Hybrid Racing




## Step 1 — Cable to transmission





- Begin by determining which shifter cable insert you'll need to use on the transmission.
- In this cable set, you will find two sized inserts.
- Depending on the year the transmission was built it will use one of the two.
- The insert should slide on the transmission gear selector pin and should have no slack.

#### Step 2 — Cable to transmission







- Install the shifter cable insert that fits your transmission and use the supplied retaining clip to keep it in place.
- Install the shifter cable end link to the gear selector and make sure you have the big end of the insert sitting flat against the gear selector. If the retaining clip is on the bottom it can freeze and bend the cable, preventing it from moving.
- Install the shifter cable to into the cable bracket, using a spring C clip.

#### Step 3 — Cable to transmission







- Install the remaining shifter cable onto the gear selector and use the supplied clip to keep it in place.
- Then, install the cable in the bracket and lock it in place using a spring C clip.

#### **Step 4** — Cable to transmission



 The cables should be completely connected to the transmission at this point.

#### Step 5 — Cable to shifter








- Connect the shifter cable to the TSX shifter by sliding it through he cable hole.
- Once the cable is in the shifter, you can clip the end link in place.
- Use a spring C clip to hold the cable to the shifter.

#### Step 6 — Cable to shifter





Now install the other cable in the same way as the previous cable. Use the supplied clip and attach
it to the shifter arm.

### Step 7 — Install Complete





The cables are now installed. Depending on the application, be sure to keep the cables away from all heat sources.